


Elle Quick Reference Guide



- A Proximity & light sensor
- B Camera
- C USB
- D Reset key
- E Speaker
- F Microphones
- G LAN/Power over Ethernet


Elle is designed to be wall mounted in portrait orientation.

Elle requires a minimum mounting depth of 22mm from the back side of Elle plus room for cables. Power is supplied by a standard POE injector that meets the IEEE 802.3af standard. Elle can also be connected to networks via a hard wired Ethernet connection.

1. Installing Elle:

a. Mounting height


The recommended mounting height for Elle is 1450 mm - 1650 mm (57" - 65") above the finished floor.



b. Rough-in


Elle has been designed to mount to a EU/CH, NEMA single-gang junction box, US/NEMA standard single-gang junction box.

The mounting bracket, included in the box, should be attached with included screws (#5 for EU/CH, #6 for US).



c. Portrait Mounting

Install the single-gang box junction box or low-voltage mounting bracket in its normal orientation.




d. Installing the mounting bracket

Using the included #5-24 screws to mount the mounting bracket onto the EU/CH single-gang junction box.


Using the included #6-32 screws to mount the mounting bracket onto the US/NEMA single-gang junction box.



EU/CH single-gang junction box:




US/NEMA single-gang low-voltage mounting bracket:



f. Installing Elle on the wall

Position Elle for the portrait mounting. Align the mounting bracket evenly in the single-gang box and gently press it towards the mounting bracket/wall. Elle snaps in when pushed to its mounting bracket.

CAUTION: DO NOT PRESS DIRECTLY ON THE SCREEN
When installing on to the mounting bracket, press only on the frame edges.




e. Connecting Elle to power and Ethernet

POE Connection

POE connection requires the IEEE 802.3af standard. Use a network switch or PoE injector that meets this standard.

Connect Elle using a standard T568A or T568B Ethernet cable from the network switch to the LAN/POE connector on the back of Elle.



g. Mounting Elle

Align the mounting bracket hooks with the mounting slots and gently press Elle towards the mounting bracket/wall.

Make sure the mounting hooks are properly engaged.

